

Changing Time and Date on the Panasonic 576 or 576 HD Systems

From extension 10 or 100 with the handset in the cradle

- 1.) Press the on/off Key
- 2.) Press the Program Key
- 3.) Press the * Key twice (**)
- 4.) Press 9999
- 5.) Press FF8 Key (2nd row above key pad/ 2nd key) (reading from left to right) lighted key
- 6.) Press 1 on your Key pad, then press Hold
- 7.) Press Hold again until Date –Time appears on your display
- 8.) Press Hold again until Date appears on your display: enter current date: example- Sept. 1, 2000 would be 00 09 01
- 9.) Press Hold after date entered
- 10.) Time should appear on your display. Enter current time: example- 1:39 pm would be 1339 (military time). Example, 8:15 am would be 0815.
- 11.) Press hold after time is entered
- 12.) Day of the week should appear.
- 13.) Day of the week should set itself correctly, if date and time are correct. 1=Mon, 2= Tues, 3= Wed, 4=Thurs, 5=Fri, 6=Sat, and 0=Sun.
- 14.) Press on/off to end.