

INSTRUCTIONS FOR SETTING CLOCK ON DBS & DBS-824 SYSTEM

FROM EXTENSION 10 or 100:

WITH THE HANDSET IN THE CRADLE:

- 1) PRESS THE ON/OFF KEY - INTERCOM DIAL TONE WILL BE HEARD
- 2) PRESS THE "PROG" KEY
- 2) WITH THE TELEPHONE DIAL, PRESS THE "#" KEY TWICE - THE DISPLAY WILL SHOW "PROGRAM MODE"
- 3) PRESS THE KEY YOU NORMALLY USE TO ANSWER LINE 1
- 4) WITH THE TELEPHONE DIAL, PRESS THE NUMBER "1" FOLLOWED BY THE "#" KEY
- 5) PRESS THE NUMBER "2" FOLLOWED BY THE "#" KEY
- 6) ENTER THE TIME IN 24 HOUR FORMAT USING THE TELEPHONE DIAL, I.E.:
7:00AM WILL BE ENTERED AS "0700". 3:00PM, AS "1500" ETC
- 7) PRESS THE # KEY
- 8) PRESS THE ON/OFF KEY

YOUR DISPLAY SHOULD NOW READ THE CORRECT TIME.

NOTE: IF AT ANY TIME DURING THE ENTRY OF THE INFORMATION ABOVE YOU LOSE YOUR PLACE OR ARE INTERRUPTED, SIMPLY HIT THE ON/OFF KEY AND YOUR PHONE WILL RETURN TO NORMAL OPERATION. THEN SIMPLY START AGAIN AT STEP 1).