

## IPK II - CLOCK/CALENDAR SETTING

To set the system time:

1. Press the **Speaker** key.
2. Dial **728**.
3. Dial two digits for the hour (24 hour clock, 13 = 1:00 PM).
4. Dial two digits for the minutes (00~59).
5. Press **Speaker** to hang up.