

IPK II - CALL FORWARD BUSY/NO ANSWER (B/NA)

To set Call Forward - Busy/No Answer at a forwarding station:

1. Pick up the handset or press the **Speaker** key.
2. Dial the **Call Forward - Busy/No Answer Service Code** (default: 744).

OR

Press the **Call Forwarding Programmable Function Key** (service code 751:13).

3. Dial **1** (Set).
4. Dial the destination extension or off-premise number.
5. Press the **Speaker** key or hang up.

Note: The destination number for voice mail in most cases is **300**.