

SV8100 - CANCEL CALL FORWARD BUSY/NO
ANSWER (B/NA)

1. Pick up the handset or press the **Speaker** key.
2. Dial the **Call Forward - Busy/No Answer Service Code** (default: 744).

OR

Press the **Call Forwarding Programmable Function Key**
(Service Code 751:13).

3. Dial **0** (Cancel).
4. Press the **Speaker** key or hang up.