

SV8100 - LAST CO/PBX NUMBER REDIAL

1. Without lifting the handset, press the **Redial** key.
2. To redial the last number, press **#**.

OR Search for

the desired number from the redial list by pressing the **List Softkey** and then the **Redial Softkey**.

3. Press the **Up Arrow/Down Arrow** or **VOLUME UP/VOLUME DOWN** keys to search for the desired number.
4. Lift the handset or press **Speaker** to place the call.